
coway

Coway Air Purifier

AP-1019C

This product is for domestic market only. Product voltage does not work overseas.
For your safety and proper use of the product, please read this user manual before use.
Warranty card is included in this user manual.
English / Thai




This paper can be recycled.

FEATURES


| Real-time Air Quality Display

The pollution sensor allows you to check the indoor air condition in real time through the four-level color display.



| Superior Air Cleaning


In order to remove fine dust in the indoor air, the product uses a powerful ultra-fine dust collection filter and optimized filter system to remove contaminants quickly.



| Filter Alarm Indicator for Replacement


It notifies the filter replacement cycles for the convenience of customer's filter management.

- HEPA / DEODORIZATION




| Customizable High-Performance Filter System

Its structure allows customers to remove the filter easily for cleaning / replacement.



| Sophisticated Design

Slim and sophisticated design that fits everywhere.



DEAR CUSTOMERS

Thank you for using the **Coway air purifier.**
Please read this user manual carefully for correct use and maintenance of the product.
You can refer to the user manual to troubleshoot for product issues while using it.
Please keep this user manual in a safe place as it includes the product warranty.

| CONTENTS

For Information

| 03 | SAFETY INFORMATION
Danger
Warning
Caution
| 07 | PARTS NAME
| 09 | AIR PURIFICATION PROCESS

How to use

| 10 | BEFORE USE
How to install Filter
| 11 | INDICATORS AND BUTTONS
| 13 | HOW TO USE
| 14 | ADJUST PARTICLE SENSOR

Maintenance

| 15 | HOW TO CLEAN
Product
Filter
| 17 | HOW TO REPLACE FILTER

Others


| 19 | TROUBLESHOOTING
| 20 | SPECIFICATION
| 21 | WARRANTY CARD

- Please keep the user manual in an accessible area where it can be seen. -

SAFETY INFORMATION

The following information is for user safety that should be observed.

It is to ensure user safety and prevent property damage. Please read the precautions carefully and use the product correctly.



220 V – 240 V~ 50 Hz, 60 Hz only

DANGER : Failing to follow the precautions below may result in serious injury or even death.

- ⚠ Do not use damaged power plugs or loose sockets.
- ⚠ The power plug must be plugged into 220 v – 240 v~ 50 hz, 60 hz.
- ⚠ Do not pull on the power cord to move the device.
- ⚠ Do not touch the power plug with wet hands.
- ⚠ To avoid damaging or warping the power cord, do not use excessive force to bend the power cord or put heavy objects on top of it.
- ⚠ Do not repeatedly connect and disconnect the power plug.
- ⚠ If water enters the power supply, unplug the power and completely dry before using again.
- ⚠ Be sure to unplug the power during product repair, maintenance or part replacement.
- ⚠ If the power plug's pins or contact area become covered in dust or water, wipe them thoroughly.
- ⚠ Do not plug several electric appliances into one socket, and use only a dedicated socket.
- ⚠ Unplug the power when not used for a long time.
- ⚠ Do not carelessly connect or tamper with the power cord.
- ⚠ If the power cord is damaged, do not replace it yourself. Contact a service center to have it replaced.
- ⚠ Do not put on top of electric products like heaters or televisions.

⚠ Do not use or store combustible gases or flammable materials near this product.

⚠ If there is a strange sound, burning smell, or smoke from the device, immediately unplug the power plug and contact a service center.

⚠ Never immerse the product in water.

⚠ Do not spray flammable materials such as insecticides or air fresheners on the intake.

⚠ Do not open, repair, or modify the device yourself.

⚠ Do not put bowls of water, chemicals, food, small metal objects, or flammable materials on top of this product.

⚠ Unplug the power before cleaning.

⚠ If the purifier falls over and gets wet during use, A/S maintenance is required before further use.

⚠ Do not spray water directly on the device or use benzene, thinners, etc. to wipe it during cleaning.

⚠ Do not insert sharp objects such as picks into the air quality sensor.

⚠ Do not put fingers or foreign matter (pins, sticks, coins, etc.) into the vent.

⚠ Do not let children hang from or climb on the purifier.

⚠ Be careful that children do not put their hands in the vent.

⚠ Replace the filter with a new one when the time comes.

⚠ Do not spray water directly on the purifier.

SAFETY INFORMATION

WARNING : Failing to follow the precautions below may result in considerable physical injury or property damage.

- ⚠ Do not unplug by pulling on the power cord.
- ⚠ Plug into a power socket connected to an earth leakage circuit breaker (current sensitivity 30 mA or less).
- ⚠ If extending the power cord, only use with sockets and cords of 250V/15A and use by itself.

CAUTION : Failing to follow the precautions below may result in slight physical injury or property damage.

- ⚠ Do not unplug the power or move the purifier while it is operating.
- ⚠ If unusual sound, odor, or smoke comes from the purifier, immediately unplug the power and call our service center.
- ⚠ Do not excessively impact or use excessive force on this product.
- ⚠ Do not use extreme force on the purifier.
- ⚠ Do not push or lean on the purifier. The purifier may fall over.
- ⚠ Do not use for a long time in places that are sealed or where children, the elderly, or sick people are.
- ⚠ Do not block the vent with laundry or curtains.
- ⚠ Remove dust from the pre-filter with a vacuum cleaner or water.
- ⚠ Periodically wash the pre-filter and dry it well in a shady place with good ventilation.
- ⚠ People with physical, sensory, or mental impairment as well as children must be supervised or guided while using the device.
- ⚠ It is advisable to supervise children so they do not play with the device.

⚠ This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

⚠ Where to place the air purifier

⚠ Do not install in places with a lot of humidity or dust or places where water(rainwater) splashes.

⚠ Do not use in baths, showers, swimming pools, or other areas where the purifier may be in direct contact with water.

⚠ Do not install on a slope.

⚠ Use at least 20 cm away from walls or other objects on each side.

⚠ Install the purifier in a place where it is not blocked on any side so air can circulate well.

⚠ Install at least 2 m away from TVs and other electronic items.

⚠ Do not use in BBQ or other restaurants where odor, smoke, or oil may occur.

⚠ Do not use in direct sunlight.

⚠ Do not install in a high place.

⚠ Do not block the vent with laundry or curtains.


⚠ Do not place the unit behind furniture.

⚠ Install the unit so the clean air can circulate free towards the roof.


READ AND SAVE THESE INSTRUCTIONS

PARTS NAME

| Front / Back



| Top



| Accessories



User Manual



One-sheet Manual

AIR PURIFICATION PROCESS

| Pre-filter


Removes large dust particles, mold, hair, and pet hair.

| DEODORIZATION filter

The granular activated carbon filter, which is effective in removing odor and hazardous gas, removes food smell and bad odors in the house.

| HEPA filter

High performance HEPA filter has been applied for superior performance in removing fine dust and cigarette smoke.




1. Pre-filter 2. DEODORIZATION filter 3. HEPA filter

| Please check before use!

⚠ The product is for 220 V – 240 V~ 50 Hz, 60 Hz only.

Make sure to connect the power plug to a grounded 220 V- 240 V~ 50 Hz, 60 Hz outlet.



| How to install filter


Tips

- Be sure to remove the packaging vinyl before installing the filter.
- Use the filter indoors only.
- Unplug the power cord from the outlet when not using the product.
- Check the front of the filter when installing it.

▶ Filter assembly sequence : DEODORIZATION filter → HEPA filter

1. Open the front cover.


Pull the top of the front cover to open it.




2. Take out the filter and remove the packaging vinyl.

Remove the packaging plastic from all filters except the pre-filter and assemble the product according to the filter assembly sequence.

∗ Filter assembly sequence : DEODORIZATION filter → HEPA filter







3. Fix the front cover.

Align the two projections on the bottom of the front cover with the grooves and push in the cover to fix it.


∗ The product will not operate if the front cover is not fixed correctly.





INDICATORS AND BUTTONS

| Indicators






❶ Auto Mode Indicator

If you select the auto mode, the auto mode indicator is lit.



❷ Silent Mode Indicator

If you select the silent mode, the silent mode indicator is lit.



❸ Air Volume Mode Indicator

If you select air volume level 1/2, the indicator is lit.



❹ Filter Alarm Indicator

When it is time to replace the filter, an alarm is turned on.




❺ Pollution Level Indicator

This indicator displays the indoor pollution level in the color of the lamp (4 levels).

∗ Level 1 (Blue) → Level 2 (Green) → Level 3 (Yellow) → Level 4 (Red)

| Buttons



1 Power button **2** Mode button **3** Mood / Filter Reset button

1 Power button

Use the button to turn the product on and off.

∗ When the product is activated initially, it will operate in auto mode and restarting the product during operation will initiate the operation mode prior to powering off.

2 Mood button

Press the Mode button to select the AUTO → SILENT → Level 1 → Level 2.

3 Mood / Filter Reset button

Use when turning ON/OFF the pollution level indicator.

The pollution level indicator is turned off after pressing the button once, and the pollution indicator is turned on after pressing the button one more time.


HOW TO USE


Tips

- Plug the power cord into an outlet before operating the product.
- The product operates in auto mode by default when turned on.

| How to Operate Product Manually


Press the Power button to turn on the power. Press the Mode button to select the desired air volume.
(AUTO → SILENT → Level 1 → Level 2)






| How to Use Auto Mode

Press the Power button to turn on the power. Press the Mode button to select the desired air volume.
(AUTO → SILENT)





| Auto Mode

The product operates automatically with ideal air volume (Auto level 1 → Auto level 2 → Auto level 3) according to indoor pollution level detected by the sensor. This mode is convenient for general users.

	Pollution Level 1	Pollution Level 2	Pollution Level 3,4
Air Volume	Auto Level 1	Auto Level 2	Auto Level 3

∗ While sleeping, it is recommended to use 'Silent Mode' as the amount of air volume may change due to the change in pollution level.

∗ If the clean state is maintained for a certain period of time in the auto mode, it is switched to the silent mode. If the pollution level changes, it is operated in the auto mode.

| Silent Mode


This mode minimizes the air volume during operation for a quiet and pleasant environment. In this Operation mode, low noises and low power consumptions are expected.

ADJUST PARTICLE SENSOR


How to adjust the sensitivity of the particle sensor

When the product is shipped out, the pollution sensor is set to standard sensitivity. If the pollution level stays at the highest level after 2 hours of operation or stays at the lowest level for more than 1 hour when the air does not seem clean, users can adjust the sensitivity of the pollution sensor as follows.


1. While the product is operating, press the Power button and the Mode button at the same time for more than 2 seconds.



2. The mode indicator flashes at an approximately 0.5 second interval.




3. Press the Mode button to adjust it to the desired sensitivity.
   The mode indicator blinks as shown below once sensor sensitivity has been selected.



SILENT	Level 1	Level 2
High	Standard	Low

4. Press the Power button and the Mode button at the same time for more than about 2 seconds, the selected sensitivity will be inputted and the product will start operating normally.
   ✳ If the Power button and the Mode button are not pressed for 10 seconds, the selected sensitivity of the sensor is automatically entered.




HOW TO CLEAN

Tips


- Always unplug the power cord before cleaning.
- Do not use organic solvents (thinner, etc.), bleach, or detergents containing chlorine or abrasives to clean the product.
- Do not immerse the product in water or spray water on it.


How to Clean Pollution Sensor (every two months)

1. Use a soft brush or vacuum cleaner to clean the air inlet and the air outlet of the pollution sensor.
   ∗ Be careful not to let dust fall inside the product when cleaning.



2. Open the pollution sensor cover at the rear top of the product. (Use the grove of the pollution sensor' cover to open the cover) Soak a cotton swab in water and wipe off the lens, the dust inlet and outlet, then wipe it off with dry cotton swab to remove moisture from it.
   ∗ Performance of pollution detection sensor may decrease if not cleaned regularly.
   ∗ Clean more often in environment with heavy dust presence.






How to Clean Front Cover

Use a soft cloth or brush to wipe off dusts on the surface of the front cover.


∗ Use slightly wet cloth to wipe when contamination is high (Do not use abrasive).



How to Clean Main Body of Product

Use a dry and soft cloth to wipe it.

∗ Use slightly wet cloth to wipe when contamination is high (Do not use abrasive).




Tips


- Always unplug the power cord before cleaning the filter.
- The pre-filter can be restored by removing dust or washing with water.
- Failure to clean the pre-filter for a long time may result in poor product performance.
- The HEPA filter and deodorization filter cannot be restored by cleaning. Never wash these filters with water.

| Pre-filter (2 ~ 4 weeks)


1. The pre-filter can be easily removed without disassembling the product. Pull the Pre-filter handle to take it out.
   ✳ Be careful not to let dust fall off when removing.



2. Remove dust with a vacuum cleaner or water depending on the degree of pollution.
   ✳ Be careful not to let dust fall inside the product when cleaning.



3. Assembling with one touch is convenient. After the pre-filter is completely dried, push it completely to the end of product.



HOW TO REPLACE FILTER

| How to Replace

- Refer to the filter installation method on page 10 to replace the filter.
- Be sure to check the front side when installing the filter.
- Use genuine Coway filter to maintain optimal performance of the product.
- Always unplug the power cord before replacing the filter.

| Filter Cleaning and Replacement Cycle

Filter	Cleaning/Replacement Time	Cleaning/Replacement
Pre-filter	Once/2-4 weeks	Clean and wash
DEODORIZATION filter	Once/24 months	Replacement
HEPA filter	Once/12 months	Replacement

✳ It is based on 8-hour use per day at level 2 air volume.


✳ Filter replacement cycle is a recommendation and may vary depending on environment.

Tips


- The cover with the filter attached may damage if it is dropped while moving, so do not move it upside down.
- Pre-filter, DEODORIZATION filter, and HEPA filter are consumables.

How to Replace HEPA / DEODORIZATION filter (Replace every 12 / 24 months)


When the HEPA filter/DEODORIZATION filter alarm indicator is on, replace it.




1. Open the front cover and remove the filter set entirely.
   ✳ It prevents dust generation inside the space.




2. Move to the place where the filter replacement is possible and separate the HEPA filter and DEODORIZATION filter respectively.




3. Clean/Wash the area except the filter and dry it before assembling the new filter.
   ✳ Check the front display of the filter.
   ✳ Assemble the deodorization filter and the HEPA filter respectively.



4. After assembling to the product, close the front cover.



5. Reset the alarm by pressing the Mood / Filter Reset button for 3 seconds.



TROUBLESHOOTING

The air purifier may malfunction due to lack of familiarity and minor causes even though the product is not broken. Check the following in such a circumstance to resolve the issue easily without assistance from the service center. If the problem persists after checking the items below, please contact the service center.

Symptom	Checkpoint	Measures to take
No air is coming out.	• Is the power cord plugged in?	Plug the power cord into a 220 V- 240 V~ 50 Hz, 60 Hz outlet.
	• Are all the indicators off?	Press the Power button and select the desired function.
	• Is there a power outage?	Use the product after the electricity is restored.
The air volume does not change.	• Is the Auto Mode indicator on?	Air volume selection is available only in Manual Mode (normal).
	• Is the Silent Mode indicator on?	Air volume selection is available only in Manual Mode (normal).
The air volume has weakened considerably.	• Has the filter cleaning or replacement time passed?	Check the filter cleaning and replacement cycle and clean or replace the filter.
The pollution level does not change.	• Is there dirt on the pollution sensor lens?	Clean the pollution sensor lens. (Refer to P. 15.)
	• Does the pollution level remain at High?	Adjust the pollution sensor's sensitivity to Low or Standard. (Refer to P. 14.)
	• Does the pollution level remain at Low?	Adjust the pollution sensor's sensitivity to High or Standard. (Refer to P. 14.)
There is a bad smell coming our of the air outlet.	• Has the filter cleaning or replacement time passed?	Check the filter cleaning and replacement cycle and clean or replace the filter.
The pollution level indicator is flashing.	• Contact the service center.	
Other functional defects	• Check the problem, unplug the power cord, and contact the service center.	

SPECIFICATION

Product Name	**Air Purifier**
Model Name	AP-1019C
Rated Voltage	220 V- 240 V~ 50 Hz, 60 Hz
Phase	Single phase
Power Consumption	35 W
Product Insulation Class	Class 2 equipment ⧈
Dust Collection Method	Mechanical dust collection (HEPA filter)
Installation Location	Indoor
Product Size	340 mm (width) × 165 mm (length) × 469 mm (height)
Product Weight	5.5 kg

There may be slight changes to the specifications for improving the product's performance.

WARRANTY CARD OR WARRANTY LETTER
TWO YEAR LIMITED WARRANTY
AIR PURTFIER AP-1019C(“PRODUCT”)

Model:
Serial Number:
Customer Name: **(“OWNER”)**
Date of Purchase:

What This Warranty Covers:

Commencing with the date of purchase of the Product and continuing for a period of Two years, if manufacturing defects in the Product cause the Product to not operate properly for its intended use, then subject to the exclusions, conditions, and limitations contained herein, COWAY at its sole option will repair or replace the Product.

Decisions as to the extent of repair or replacement required will be made solely by COWAY.

The remedy under this Warranty is available only for that portion of the Product exhibiting defects at the time of the warranty claim. The replacement Product as well as any remaining original Product will be warranted only for the original two years warranty period. This limited warranty applies only to Product used for an application specified by COWAY for the Product and applied in strict accordance with COWAY published specifications in effect at the time of application. IF PRODUCT IS USED FOR OTHER THAN ITS INTENDED PURPOSE, IT IS SOLD AS IS AND WITHOUT ANY EXPRESS

OR IMPLIED WARRANTIES, INCLUDING OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

What This Warranty Does Not Cover:

This Warranty warrants that the Product will be free from manufacturing defects which affect the ability of the Product to operate for its intended use; it is not a warranty that the Product will never require repairs or to undertake responsibilities, liabilities or obligations other than those specifically identified in the preceding section. COWAY is not responsible or liable for personal injury or property damage of any kind, even if arising from a breach of this Warranty.

Limitations and Exclusions:

TO THE EXTENT PERMITTED BY APPLICABLE LAW, COWAY DISCLAIMS ANY OTHER WARRANTY EXPRESS OR IMPLIED, THAN THAT PROVIDED FOR HEREIN. THIS WARRANTY IS IN LIEU OF AND EXCLUDES ALL OTHER WARRANTIES, GUARANTEES, CONDITIONS AND REPRESENTATIONS, EXPRESS

OR IMPLIED, ORAL OR WRITTEN, STATUTORY OR OTHERWISE, INCLUDING BUT NOT LIMITED TO ANY IMPLIED CONDITIONS OR WARRANTIES AS TO THE MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OF THE COWAY PRODUCT.

SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU.

COWAY DOES NOT AUTHORIZE ANY PERSON INCLUDING ITS REPRESENTATIVES, TO MAKE ANY REPRESENTATION OR TO OFFER ANY WARRANTY, CONDITION OR GUARANTY IN RESPECT OF THE PRODUCT OTHER THAN THIS WARRANTY. THIS LIMITED WARRANTY SHALL BE THE OWNER’S SOLE AND EXCLUSIVE REMEDY AGAINST COWAY AND COWAY SHALL NOT BE LIABLE FOR ANY CONSEQUENTIAL, EXEMPLARY, SPECIAL, INCIDENTAL OR OTHER DAMAGES INCLUDING, BUT NOT LIMITED TO, LOSS OF PROFITS, AND LOSS OF USE. INCIDENTAL, CONSEQUENTIAL AND EXEMPLARY DAMAGES SHALL NOT BE RECOVERABLE EVEN IF THE REMEDIES OR THE ACTIONS PROVIDED FOR IN THIS WARRANTY FAIL OF THEIR ESSENTIAL PURPOSE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATION OR EXCLUSION MAY NOT APPLY TO YOU. COWAY SHALL NOT BE LIABLE FOR ANY DAMAGES WHICH ARE BASED UPON NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY OR ANY OTHER LEGAL THEORY OF LIABILITY OTHER THAN THE EXCLUSIVE LIABILITY SET FORTH IN THIS WARRANTY.

Limitations on Implied Warranties:

Any implied warranty of merchantability or fitness for a particular purpose or use, shall be limited to the duration of the foregoing express written warranty.

Conditions of Warranty:

COWAY's continuing liability under this Warranty is conditioned upon the following:

a) The defect or damage is not causedby or is the result of: abnormal use or conditions; improper storage, unauthorized modifications or repair; misuse, neglect, accident, alteration, improper installation or other acts that are not the fault of Coway or the manufacturer of the product or that are not covered by the manufacturer's warranty;
b) The Product has not been altered, modified or repaired without prior written approval of COWAY;
c) The OWNER has notified COWAY in writing of any failure of the Product covered by this Warranty within thirty (30) days following such failure;
d) There has been no misuse, abuse or negligence with respect to the Product on the part of the OWNER.

Waiver:

COWAY's failure at any time to enforce or rely upon any of the terms or conditions stated herein shall not be construed to be a waiver of its rights hereunder.

Obtaining Warranty Service and OWNER'S Duties:


If the Product fails to operate for its intended purpose, then notify COWAY or its Representative Agency, within 48 hours or within the next business day after discovery of any defect in the Product. The OWNER must give written notice to COWAY no later than thirty (30) days after a defect is discovered or should by reasonable diligence have been discovered. Claims under this Warranty will require proof of purchase by the OWNER.

COWAY
Add : COWAY Co., Ltd. 136-23, Yugumagoksa-ro, Yugu-eup, Gongju-si, Chungcheongnam-do, Korea Tel. : Korea-Seoul : +82-1588-5100

คุณสมบัติ


| การแสดงคุณภาพอากาศแบบเรียลไทม์

เซนเซอร์มลพิษช่วยให้คุณสามารถตรวจสอบสภาพอากาศภายในอาคารได้แบบเรียลไทม์ผ่านการแสดงผลสีสี่ระดับ




| การฟอกอากาศประสิทธิภาพเยี่ยม

ในการขจัดฝุ่นละเอียดภายในอากาศในอาคาร ผลิตภัณฑ์ใช้ตัวกรองเก็บฝุ่นละเอียดพิเศษ และระบบการกรองที่มีประสิทธิภาพเพื่อขจัดสิ่งปนเปื้อนอย่างรวดเร็ว




| สัญญาณเตือนเพื่อเปลี่ยนตัวกรอง

เตือนให้ทราบรอบการเปลี่ยนตัวกรอง เพื่อให้ความสะดวกแก่ผู้ใช้ในการจัดการตัวกรอง
- ตัวกรองPre-filter, HEPA / ขจัดกลิ่น




| ระบบกรองประสิทธิภาพสูงที่ปรับแต่งได้

โครงสร้างของระบบช่วยให้ลูกค้าสามารถถอดตัวกรองได้โดยง่าย
เพื่อนำออกมาทำความสะอาด/เปลี่ยน



| การออกแบบสวยงาม ล้ำสมัย

การออกแบบที่กะทัดรัด สวยงาม เหมาะกับทุกสภาพแวดล้อม



เรียน

ขอขอบคุณที่เลือกใช้ เครื่องฟอกอากาศ **Coway**
โปรดอ่านคู่มือผู้ใช้นี้โดยละเอียด เพื่อให้ทราบเกี่ยวกับวิธีการใช้งานและบำรุงรักษาผลิตภัณฑ์อย่างถูกต้อง
คุณสามารถดูคู่มือผู้ใช้นี้เพื่อแก้ไขปัญหาเกี่ยวกับผลิตภัณฑ์ในขณะใช้งานได้

สารบัญ

ข้อมูล

| 03 | ข้อมูลเพื่อความปลอดภัย
อันตราย
คำเตือน
ข้อควรระวัง
| 07 | ชื่อชิ้นส่วน
| 09 | กระบวนการฟอกอากาศ

วิธีใช้

| 10 | ก่อนการใช้งาน
วิธีการติดตั้งตัวกรอง
| 11 | สัญญาณและปุ่ม
| 13 | วิธีใช้
| 14 | ปรับเซนเซอร์ฝุ่นละออง

การบำรุงรักษา

| 15 | วิธีการทำความสะอาด
ผลิตภัณฑ์
ตัวกรอง
| 17 | วิธีการเปลี่ยนตัวกรอง


อื่นๆ

| 19 | การแก้ไขปัญหา
| 20 | ข้อมูลจำเพาะ

- โปรดเก็บคู่มือผู้ใช้นี้ไว้ในที่ซึ่งเข้าถึงได้ง่ายและสามารถมองเห็นได้ -

ข้อมูลเพื่อความปลอดภัย

ข้อมูลต่อไปนี้มีให้เพื่อความปลอดภัยของผู้ใช้
โดยมีขึ้นเพื่อให้ผู้ใช้มีความปลอดภัยและป้องกันความเสียหายต่อทรัพย์สิน
โปรดอ่านข้อควรระวังนี้โดยละเอียดและใช้ผลิตภัณฑ์อย่างถูกต้อง



220 V – 240 V~ 50 Hz, 60 Hz เท่านั้น

⚠ อันตราย: หากไม่ปฏิบัติตามข้อควรระวังด้านล่าง อาจทำให้เกิดการบาดเจ็บร้ายแรงหรือเสียชีวิต

- ⚠ **ห้ามใช้ปลั๊กไฟที่เสียหายหรือเต้ารับไฟฟ้าที่หลวม**
- ⚠ **ปลั๊กไฟต้องต่อเข้ากับเต้ารับไฟฟ้า** 220 v – 240 v~ 50 hz, 60 hz
- ⚠ **ห้ามดึงสายไฟเพื่อเคลื่อนย้ายผลิตภัณฑ์**
- ⚠ **ห้ามสัมผัสปลั๊กไฟขณะมือเปียก**
- ⚠ **เพื่อหลีกเลี่ยงความเสียหายหรือทำให้สายไฟบิดงอ โปรดอย่าใช้แรงมากเกินไปเพื่อหักงอสายไฟหรือวางของหนักทับสายไฟ**
- ⚠ **อย่าต่อและถอดปลั๊กไฟซ้ำ ๆ หลายครั้ง**
- ⚠ **ถ้าน้ำเข้าสู่แหล่งจ่ายไฟ ให้ถอดปลั๊กไฟออกและรอให้แห้งสนิทก่อนที่จะใช้**
- ⚠ **ถอดปลั๊กไฟระหว่างการซ่อมผลิตภัณฑ์ การบำรุงรักษาหรือการเปลี่ยนชิ้นส่วน**
- ⚠ **ถ้าขาของปลั๊กไฟหรือหน้าสัมผัสของปลั๊กมีฝุ่นหรือน้ำเกาะ ให้เช็ดให้แห้งสะอาด**
- ⚠ **อย่าเสียบปลั๊กอุปกรณ์ไฟฟ้าหลายอย่างเข้ากับเต้ารับเดียว และใช้เต้ารับกับอุปกรณ์นี้เพียงอย่างเดียว**
- ⚠ **โปรดถอดปลั๊กไฟออก ถ้าจะไม่ใช้ผลิตภัณฑ์เป็นเวลานาน**
- ⚠ **อย่าเสียบปลั๊กโดยไม่ระมัดระวัง หรือแก้ไขดัดแปลงสายไฟ**
- ⚠ **ถ้าสายไฟเสียหาย โปรดอย่าเปลี่ยนด้วยตนเอง โปรดติดต่อศูนย์บริการเพื่อเปลี่ยนชิ้นส่วน**
- ⚠ **อย่าวางไว้บนผลิตภัณฑ์เครื่องไฟฟ้า เช่น เครื่องทำความร้อนหรือโทรทัศน์**

⚠ ห้ามใช้หรือเก็บก๊าซไวไฟหรือวัตถุไวไฟใกล้กับผลิตภัณฑ์นี้

⚠ ถ้ามีเสียงผิดปกติ มีกลิ่นเหม็นไหม้ หรือควันออกจากอุปกรณ์ ให้ถอดปลั๊กไฟและติดต่อศูนย์บริการทันที

⚠ ห้ามจุ่มผลิตภัณฑ์ในน้ำโดยเด็ดขาด

⚠ ห้ามพ่นสารระเหย เช่น ยาฆ่าแมลงหรือสเปรย์ปรับอากาศลงบนอุปกรณ์

⚠ ห้ามเปิด ซ่อมแซม หรือดัดแปลงอุปกรณ์ด้วยตนเอง

⚠ ห้ามวางถ้วยน้ำ สารเคมี อาหาร วัตถุที่เป็นโลหะขนาดเล็ก หรือวัตถุไวไฟที่ด้านบนของผลิตภัณฑ์นี้

⚠ ถอดปลั๊กไฟก่อนที่จะทำความสะอาด

⚠ ถ้าเครื่องฟอกอากาศล้มและเปียกระหว่างการใช้งาน จะต้องมีการบำรุงรักษาหลังการขายก่อนที่จะใช้งานได้อีกครั้ง

⚠ ห้ามฉีดน้ำลงบนอุปกรณ์โดยตรง หรือใช้เบนซิน ทินเนอร์ ฯลฯ เพื่อเช็ดระหว่างการทำความสะอาด

⚠ ห้ามสอดของแหลม เช่น ไม้แหลมในเซนเซอร์คุณภาพอากาศ

⚠ อย่าสอดนิ้วหรือสิ่งแปลกปลอม (เข็มกลัด ไม้แหลม เหรียญ ฯลฯ) ในช่องอากาศ

⚠ อย่าให้เด็กโหนหรือปีนเครื่องฟอกอากาศ

⚠ ระวังอย่าให้เด็กใส่มือเข้าไปในช่องอากาศ

⚠ เปลี่ยนตัวกรองใหม่เมื่อครบกำหนด

⚠ อย่าพ่นน้ำบนเครื่องฟอกอากาศโดยตรง

ข้อมูลเพื่อความปลอดภัย

คำเตือน: หากไม่ปฏิบัติตามข้อควรระวังด้านล่างนี้ อาจทำให้เกิดการบาดเจ็บรุนแรงหรือทรัพย์สินเสียหาย

- **อย่าถอดปลั๊กไฟด้วยการดึงที่สายไฟ**
- **เสียบปลั๊กเข้ากับเต้ารับไฟฟ้าที่มีเบรกเกอร์วงจรลงกราวด์ (ความไวต่อกระแสไฟฟ้าไม่เกิน 30 mA)**
- **ถ้ามีการต่อสายไฟเพิ่มเติม ให้ใช้เต้ารับและสายไฟที่มีพิกัด 250V/15A และไม่ใช้ร่วมกับอุปกรณ์อื่น**

ข้อควรระวัง: หากไม่ปฏิบัติตามข้อควรระวังด้านล่างนี้ อาจทำให้เกิดการบาดเจ็บหรือทรัพย์สินเสียหายเล็กน้อย

- **อย่าถอดปลั๊กหรือเคลื่อนย้ายเครื่องฟอกอากาศขณะที่เครื่องทำงาน**
- **ถ้ามีเสียงผิดปกติ กลิ่น หรือควันออกจากเครื่องฟอกอากาศ ให้ถอดปลั๊กไฟและติดต่อศูนย์บริการของเราทันที**
- **ห้ามใช้แรงกระแทกหรือใช้แรงมากเกินไปกับผลิตภัณฑ์**
- **ห้ามใช้แรงมาก ๆ กับเครื่องฟอกอากาศ**
- **อย่าดันหรือพิงเครื่องฟอกอากาศ เครื่องฟอกอากาศอาจล้ม**
- **ห้ามใช้เป็นเวลานานในสถานที่ซึ่งมีการปิดผนึก หรือในที่ซึ่งมีเด็ก ผู้สูงอายุ หรือผู้ป่วยอยู่**
- **อย่าปิดช่องอากาศออกด้วยผ้าหรือผ้าม่าน**
- **นำฝุ่นออกจากตัวกรองล่วงหน้าด้วยเครื่องดูดฝุ่นหรือน้ำ**
- **ล้างตัวกรองล่วงหน้าและปล่อยไว้ให้แห้งสนิทในที่ร่มที่มีอากาศถ่ายเท**
- **บุคคลที่มีความบกพร่องทางร่างกาย ประสาทสัมผัส หรือจิตใจ ตลอดจนเด็กจะต้องได้รับการกำกับดูแลหรือให้คะแนะนำในขณะใช้อุปกรณ์นี้**
- **ขอแนะนำให้กำกับดูแลไม่ให้เด็กเล่นกับอุปกรณ์นี้**
- **อุปกรณ์นี้สามารถใช้งานโดยเด็กอายุ 8 ปีขึ้นไปและบุคคลที่มีสมรรถนะทางกาย ประสาทสัมผัสหรือจิตใจไม่สมบูรณ์ หรือขาดประสบการณ์และความรู้ ถ้ามีการกำกับดูแลหรือให้คำแนะนำเกี่ยวกับการใช้อุปกรณ์อย่างปลอดภัย และเข้าใจถึงอันตรายที่อาจเกิดขึ้นได้**

⚠ ตำแหน่งที่ตั้งเครื่องฟอกอากาศ

⚠ อย่าติดตั้งในที่ซึ่งมีความชื้นสูงหรือมีฝุ่นมาก หรือสถานที่ซึ่งมีน้ำ (น้ำฝน) กระเด็นถึง

⚠ ห้ามใช้ในอ่างอาบน้ำ ฝักบัว สระว่ายน้ำ และพื้นที่อื่นๆ ซึ่งเครื่องฟอกอากาศอาจสัมผัสกับน้ำโดยตรง

⚠ ห้ามติดตั้งบนพื้นที่เอียง

⚠ ใช้อุปกรณ์ห่างจากผนังและวัตถุอื่นๆ ด้านละ 20 ซม.

⚠ ติดตั้งเครื่องฟอกอากาศในสถานที่ซึ่งไม่มีสิ่งกีดขวางในด้านใดเลย เพื่อให้อากาศหมุนเวียนได้ดี

⚠ ติดตั้งห่างจากโทรทัศน์และอุปกรณ์อิเล็กทรอนิกส์อื่นๆ อย่างน้อย 2 เมตร

⚠ ห้ามใช้ในร้านอาหารประเภท BBQ หรือประเภทอื่นๆ ซึ่งมีกลิ่น ควัน หรือไอน้ำมัน

⚠ ห้ามใช้ในที่ซึ่งได้รับแสงแดดโดยตรง

⚠ ห้ามติดตั้งในที่สูง

⚠ อย่าปิดช่องอากาศออกด้วยผ้าหรือผ้าม่าน


⚠ อย่าวางอุปกรณ์ตะแคงข้าง

⚠ ติดตั้งเครื่องในลักษณะที่อากาศสะอาดสามารถหมุนเวียนโดยอิสระไปทางเพดาน


โปรดอ่านและเก็บคำแนะนำนี้ไว้

ชื่อชิ้นส่วน

ด้านหน้า / ด้านหลัง



ด้านบน



อุปกรณ์เสริม



คู่มือผู้ใช้



คู่มือแบบหนึ่งแผ่น

กระบวนการฟอกอากาศ

ตัวกรองPre-filter


ขจัดอนุภาคฝุ่นขนาดใหญ่ เชื้อรา เส้นผม และขนสัตว์เลี้ยง

ตัวกรองขจัดกลิ่น

ตัวกรองแอคทีฟคาร์บอนละเอียด มีประสิทธิภาพในการขจัดกลิ่นและก๊าซอันตราย ขจัดกลิ่นอาหารและกลิ่นอับในบ้าน

ตัวกรอง HEPA

ตัวกรอง HEPA ประสิทธิภาพสูงมีสมรรถนะที่เหนือกว่า ในการขจัดฝุ่นละเอียดและควันบุหรี่




1. **ตัวกรอง**Pre-filter 2. **ตัวกรองขจัดกลิ่น** 3. **ตัวกรอง** HEPA

ก่อนการใช้งาน

| โปรดตรวจสอบก่อนใช้งาน

⚠ **ผลิตภัณฑ์นี้ใช้กับไฟฟ้า** 220 V~240 V, 50 Hz **หรือ** 60 Hz **เท่านั้น**
โปรดต่อปลั๊กไฟเข้ากับเต้ารับไฟฟ้าที่ลงกราวด์ 220 V- 240 V~ 50 Hz, 60 Hz **เท่านั้น**



| วิธีการติดตั้งตัวกรอง


เคล็ดลับ

- โปรดนำไวนิลบรรจุภัณฑ์ออกก่อนที่จะติดตั้งตัวกรอง
- ใช้ตัวกรองภายในอาคารเท่านั้น
- ถอดปลั๊กไฟจากเต้ารับไฟฟ้าเมื่อไม่ได้ใช้ผลิตภัณฑ์
- ตรวจสอบส่วนหน้าของตัวกรองเมื่อติดตั้ง

▶ **ลำดับการประกอบตัวกรอง: ตัวกรองขจัดกลิ่น → ตัวกรอง** HEPA

1. เปิดฝาครอบด้านหน้า


ดึงส่วนบนของฝาครอบด้านหน้าเพื่อเปิด




2. นำตัวกรองที่อยู่ด้านในออกมาเพื่อแกะซองพลาสติกที่หุ้มตัวกรองอยู่ออก

แกะพลาสติกบรรจุภัณฑ์ออกจากตัวกรองทั้งหมด ยกเว้นตัวกรองด่วงหน้าและประกอบผลิตภัณฑ์ตามลำดับการประกอบตัวกรอง

∗ ลำดับการประกอบตัวกรอง: ตัวกรองขจัดกลิ่น → ตัวกรอง HEPA







3. ใส่ฝาครอบด้านหน้า

วางลิ้นสองส่วนที่ด้านล่างของฝาครอบด้านหน้าให้ตรงกับร่องและดันฝาครอบเข้าที่


∗ ผลิตภัณฑ์จะไม่ทำงานถ้าใส่ฝาครอบด้านหน้าไม่เข้าที่





สัญญาณและปุ่ม

การแสดงสัญญาณ



AUTO

❶ สัญญาณโหมดอัตโนมัติ

ถ้าคุณเลือกโหมดอัตโนมัติ
สัญญาณโหมดอัตโนมัติจะสว่าง

SILENT

❷ สัญญาณโหมดเงียบ

ถ้าคุณเลือกโหมดเงียบ สัญญาณโหมดเงียบจะสว่าง

1 2

❸ สัญญาณความแรงลม

ถ้าคุณเลือกระดับความแรงลม 1/2
สัญญาณนี้จะสว่าง

HEPA
DEODORIZATION

❹ สัญญาณเตือนตัวกรอง


เมื่อได้เวลาเปลี่ยนตัวกรอง การเตือนนี้จะทำงาน

❺ สัญญาณบอกระดับมลพิษ

สัญญาณนี้จะแสดงระดับมลพิษในอากาศเป็น
สีของไฟ (4 ระดับ)

∗ ระดับ 1 (น้ำเงิน) ⟶ ระดับ 2 (เขียว) ⟶
ระดับ 3 (เหลือง) ⟶ ระดับ 4 (แดง)

ปุ่ม



1 ปุ่มเปิด/ปิด 2 ปุ่มโหมด 3 ปุ่มไฟสัญญาณ / รีเซ็ตตัวกรอง

1 ปุ่มเปิด/ปิด

ใช้ปุ่มนี้เพื่อเปิดหรือปิดผลิตภัณฑ์

* เมื่อเปิดใช้งานผลิตภัณฑ์ครั้งแรก เครื่องจะทำงานในโหมดอัตโนมัติ และเมื่อเริ่มต้นการทำงานผลิตภัณฑ์ใหม่หลังจากที่เครื่องทำงานแล้ว จะเป็นการเริ่มต้นการทำงานในโหมดที่เครื่องทำงานอยู่ก่อนหน้านั้น

2 ปุ่มโหมด

กดปุ่มโหมดเพื่อเลือก

อัตโนมัติ → เงียบ → ระดับ 1 → ระดับ 2

3 ปุ่มไฟสัญญาณ / รีเซ็ตตัวกรอง

FILTER RESET
(3sec)

ใช้เพื่อเปิด/ปิดสัญญาณบอกระดับมลพิษ สัญญาณบอกระดับมลพิษจะปิดการทำงานเมื่อกดปุ่มหนึ่งครั้งและสัญญาณบอกระดับมลพิษจะทำงานเมื่อกดปุ่มอีกครั้ง

วิธีใช้


เคล็ดลับ


- เสียบปลั๊กไฟเข้ากับเต้ารับก่อนที่จะใช้งานผลิตภัณฑ์
- ผลิตภัณฑ์นี้จะทำงานในโหมดอัตโนมัติเป็นค่าเริ่มต้นเมื่อเปิดเครื่อง

วิธีการใช้งานผลิตภัณฑ์แบบกำหนดเอง

กดปุ่มเปิด/ปิดเพื่อเปิดเครื่อง
กดปุ่มโหมดเพื่อเลือกความแรงลมที่ต้องการ

(อัตโนมัติ → เงียบ → ระดับ 1 → ระดับ 2)







วิธีการใช้โหมดอัตโนมัติ

กดปุ่มเปิด/ปิดเพื่อเปิดเครื่อง
จากนั้นกดปุ่มโหมดเพื่อเลือกโหมดอัตโนมัติ

(อัตโนมัติ → เงียบ)





โหมดอัตโนมัติ

ผลิตภัณฑ์จะทำงานโดยอัตโนมัติโดยความแรงลมที่เหมาะสม (อัตโนมัติระดับ 1 → อัตโนมัติระดับ 2 → อัตโนมัติระดับ 3)
ตามระดับมลพิษในห้องที่เซนเซอร์ตรวจพบ โหมดนี้ให้ความสะดวกสำหรับผู้ใช้โดยทั่วไป

	มลพิษระดับ 1	**มลพิษระดับ** 2	**มลพิษระดับ** 3.4
ความแรงลม	อัตโนมัติระดับ 1	อัตโนมัติระดับ 2	อัตโนมัติระดับ 3

∗ ขณะนอนหลับ ขอแนะนำให้ใช้ 'โหมดเงียบ' เนื่องจากความแรงลมอาจเปลี่ยนไปเนื่องจากการเปลี่ยนแปลงระดับมลพิษ

∗ ถ้าอากาศมีภาวะที่สะอาดต่อเนื่องระยะหนึ่งในโหมดอัตโนมัติ เครื่องจะเปลี่ยนเป็นโหมดเงียบ ถ้าระดับมลพิษเปลี่ยนไป เครื่องจะทำงานในโหมดอัตโนมัติ


โหมดเงียบ

โหมดนี้จะลดปริมาณอากาศระหว่างการทำงานเพื่อให้สภาพแวดล้อมมีความเงียบสบาย
ในโหมดการทำงานนี้เครื่องจะมีเสียงเงียบและใช้พลังงานน้อยลง


วิธีการปรับความไวของเซนเซอร์อนุภาค

เมื่อจัดจำหน่ายผลิตภัณฑ์ เซนเซอร์คุณภาพอากาศจะถูกตั้งค่าความไวมาตรฐาน
ถ้าระดับมลพิษอยู่ในระดับสูงสุดหลังจากการใช้งานเครื่องเป็นเวลา 2 ชั่วโมง หรืออยู่ในระดับต่ำสุดเป็นเวลามากกว่า 1 ชั่วโมงโดยที่อากาศดูเหมือนไม่สะอาด ผู้ใช้สามารถปรับความไวของเซนเซอร์มลพิษดังนี้


1. ขณะที่ผลิตภัณฑ์ทำงาน ให้กดปุ่มเปิด/ปิดและปุ่มโหมดพร้อมกันเป็นเวลา 2 วินาทีขึ้นไป



2. สัญญาณของโหมดจะกะพริบโดยเว้นระยะประมาณ 0.5 วินาที




3. กดปุ่มโหมดเพื่อปรับให้มีความไวตามต้องการ
สัญญาณของโหมดจะกะพริบตามที่แสดงด้านล่าง เมื่อเลือกความไวของเซนเซอร์แล้ว



เงียบ	ระดับ 1	ระดับ 2
สูง	มาตรฐาน	ต่ำ

4. กดปุ่มเปิด/ปิดและปุ่มโหมดพร้อมกันเป็นเวลาประมาณ 2 วินาทีขึ้นไป
ความไวที่เลือกจะถูกบันทึกและผลิตภัณฑ์จะเริ่มต้นทำงานตามปกติ

∗ ถ้าไม่ได้กดปุ่มเปิด/ปิดและปุ่มโหมดภายใน 10 วินาที ความไวเซนเซอร์ที่เลือกไว้จะถูกบันทึกโดยอัตโนมัติ




วิธีการทำความสะอาด

เคล็ดลับ


- ถอดปลั๊กของเครื่องก่อนที่จะทำความสะอาดทุกครั้ง
- ห้ามใช้สารซักฟอกที่มีตัวทำละลายอินทรีย์ (ทินเนอร์ ฯลฯ) สารฟอกขาว หรือสารซักฟอกที่มีคลอรีน หรือสารที่มีฤทธิ์ขัดสีเพื่อทำความสะอาด
- ห้ามนำผลิตภัณฑ์จุ่มน้ำหรือพ่นน้ำใส่


วิธีทำความสะอาดเซนเซอร์มลพิษ (ทุกสองเดือน)

1. ใช้แปรงขนนุ่มหรือเครื่องดูดฝุ่นเพื่อทำความสะอาดช่องอากาศเข้าและช่องอากาศออกของเซนเซอร์มลพิษ
   * ระวังอย่าให้ฝุ่นเข้าสู่ผลิตภัณฑ์ขณะที่ทำความสะอาด




2. เปิดฝาครอบเซนเซอร์มลพิษที่ด้านหลังส่วนบนของผลิตภัณฑ์ (ใช้ร่องของฝาครอบเซนเซอร์มลพิษเพื่อเปิดฝา) ใช้ไม้พันสำลีชุบน้ำและเช็ดเลนส์ช่องอากาศเข้าและช่องอากาศออก จากนั้นเช็ดด้วยสำลีแผ่นแห้งๆ เพื่อไม่ให้มีความชื้นหลงเหลือ
   * ประสิทธิภาพของเซนเซอร์ตรวจจับมลพิษอาจลดลงถ้าไม่ทำความสะอาดเป็นประจำ
   * ทำความสะอาดบ่อยขึ้นในสภาพแวดล้อมที่มีฝุ่นมาก






วิธีทำความสะอาดฝาครอบด้านหน้า

ใช้ผ้านุ่มหรือแปรงขนนุ่มเพื่อเช็ดฝุ่นออกจากพื้นผิวของฝาครอบด้านหน้า
* ใช้ผ้าหมาดเพื่อเช็ดเมื่อมีความสกปรกมากเกินไป (ห้ามใช้วัสดุที่มีฤทธิ์ขัดสี)



วิธีทำความสะอาดตัวเครื่อง

ใช้ผ้านุ่มและแห้งเพื่อเช็ด
* ใช้ผ้าหมาดเพื่อเช็ดเมื่อมีความสกปรกมากเกินไป (ห้ามใช้วัสดุที่มีฤทธิ์ขัดสี)




เคล็ดลับ


- ถอดปลั๊กออกก่อนทำความสะอาดตัวกรองทุกครั้ง
- ตัวกรองPre-filterสามารถใช้ซ้ำได้หลังจากล้างทำความสะอาดฝุ่นออกด้วยน้ำ
- หากไม่ล้างตัวกรองPre-filterเป็นเวลานาน จะทำให้ผลิตภัณฑ์มีประสิทธิภาพลดลง
- ตัวกรอง HEPA และตัวกรองขจัดกลิ่นนั้นไม่สามารถทำความสะอาดเพื่อใช้ซ้ำได้ ห้ามล้างตัวกรองเหล่านี้ด้วยน้ำ

ตัวกรองPre-filter (2 ~ 4 สัปดาห์)


1. ตัวกรองPre-filterนั้นสามารถถอดออกได้ง่ายโดยไม่ต้องถอดประกอบผลิตภัณฑ์
   ดึงมือจับของตัวกรองPre-filterเพื่อนำออก
   * ระวังอย่าให้ฝุ่นร่วงหล่นเมื่อถอดออก



2. ขจัดฝุ่นด้วยเครื่องดูดฝุ่นหรือน้ำ ขึ้นอยู่กับระดับความสกปรก
   * ระวังอย่าให้ฝุ่นเข้าสู่ผลิตภัณฑ์ขณะที่ทำความสะอาด



3. ประกอบกลับเข้าที่ได้สะดวก หลังจากที่ตัวกรองPre-filterแห้งสนิท ให้ดันเข้าจนสุด



วิธีการเปลี่ยนตัวกรอง

วิธีการเปลี่ยน

- ดูวิธีการติดตั้งตัวกรองที่ระบุไว้ในหน้า 10 เพื่อเปลี่ยนตัวกรอง
- โปรดตรวจสอบว่าด้านใดเป็นด้านหน้าเมื่อติดตั้งตัวกรอง
- ใช้ตัวกรอง Coway ของแท้เพื่อรักษาประสิทธิภาพสูงสุดของผลิตภัณฑ์
- ถอดปลั๊กออกก่อนเปลี่ยนตัวกรองทุกครั้ง

ระยะเวลาทำความสะอาดและเปลี่ยนตัวกรอง

ตัวกรอง	เวลาในการทำความสะอาด/เปลี่ยน	ทำความสะอาด/เปลี่ยน
ตัวกรองPre-filter	หนึ่งครั้ง / 2-4 สัปดาห์	ทำความสะอาดและล้าง
ตัวกรองขจัดกลิ่น	หนึ่งครั้ง / 24 เดือน	การเปลี่ยน
ตัวกรอง HEPA	หนึ่งครั้ง / 12 เดือน	การเปลี่ยน

✶ อ้างอิงจากการใช้งานวันละ 8 ชั่วโมง โดยใช้ความแรงลมระดับ 2


✶ ระยะเวลาเปลี่ยนตัวกรองนี้เป็นระยะเวลาแนะนำ และอาจแตกต่างจากนี้โดยขึ้นอยู่กับสภาพแวดล้อมในการใช้งาน

เคล็ดลับ


- ฝาครอบที่มีตัวกรองติดอยู่อาจเสียหายถ้าร่วงหล่นขณะเคลื่อนย้าย โปรดอย่าย้ายโดยกลับหัว
- ตัวกรองPre-filter ตัวกรองขจัดกลิ่น และตัวกรองเก็บฝุ่นเป็นวัสดุสิ้นเปลือง

วิธีเปลี่ยนตัวกรอง HEPA / ตัวกรองขจัดกลิ่น (เปลี่ยนทุก 12 / 24 เดือน)


เมื่อสัญญาณเตือนของตัวกรอง HEPA / ตัวกรองขจัดกลิ่นทำงาน ให้เปลี่ยนตัวกรอง




1. เปิดฝาครอบด้านหน้าและนำชุดตัวกรองออกทั้งหมด
   ✳ เป็นการป้องกันการเกิดฝุ่นภายใน




2. ย้ายไปยังสถานที่ซึ่งสามารถเปลี่ยนตัวกรองได้ และแยกตัวกรอง HEPA และตัวกรองขจัดกลิ่นออกตามลำดับ
   ✳ ด้านสีเขียวหันเข้าหาตัวกรองขจัดกลิ่น และด้านสีขาวหันเข้าหาพัดลมด้านในเครื่อง




3. ทำความสะอาด/ล้างบริเวณโดยรอบยกเว้นตัวกรอง และทำให้แห้งก่อนที่จะประกอบตัวกรองตัวใหม่
   ✳ ตรวจสอบสัญลักษณ์ด้านหน้าของตัวกรอง
   ✳ ประกอบตัวกรองขจัดกลิ่นและตัวกรอง HEPA ตามลำดับ



4. หลังจากประกอบผลิตภัณฑ์ ให้ปิดฝาครอบด้านหน้า



5. รีเซ็ตการเตือนด้วยการกดปุ่มไฟสัญญาณ/รีเซ็ตตัวกรองเป็นเวลา 3 วินาที



การแก้ไขปัญหา

เครื่องฟอกอากาศอาจทำงานผิดปกติเนื่องจากขาดความคุ้นเคย และอาจมีสาเหตุเล็กน้อย
โดยที่ผลิตภัณฑ์ไม่ได้เสีย โปรดตรวจสอบสิ่งต่อไปนี้ในกรณีดังกล่าว เพื่อแก้ไขปัญหาโดยง่ายและไม่ต้องรับความช่วยเหลือจากศูนย์บริการ
ถ้าตรวจสอบข้อมูลด้านล่างแล้วปัญหายังคงอยู่ โปรดติดต่อศูนย์บริการ

อาการ	จุดที่ต้องตรวจสอบ	สิ่งที่ควรทำ
ไม่มีอากาศไหลออก	• ต่อสายไฟแล้วหรือไม่	ต่อสายไฟเข้ากับเต้ารับไฟฟ้าแบบ 220 V- 240 V~ 50 Hz, 60 Hz
	• สัญญาณทั้งหมดดับอยู่หรือไม่	กดปุ่มเปิดเครื่อง และเลือกฟังก์ชันที่ต้องการ
	• ไฟฟ้าดับหรือไม่	ใช้ผลิตภัณฑ์หลังจากที่ไฟฟ้ากลับมาใช้ได้ดังเดิม
ความแรงลม ไม่เปลี่ยนแปลง	• สัญญาณโหมดอัตโนมัติทำงานหรือไม่	การเลือกความแรงลมทำได้เฉพาะในโหมดกำหนดเอง (ปกติ)
	• สัญญาณโหมดเงียบทำงานหรือไม่	การเลือกความแรงลมทำได้เฉพาะในโหมดกำหนดเอง (ปกติ)
ปริมาณอากาศลดลงอย่างมาก	• ถึงเวลาทำความสะอาดหรือเปลี่ยนตัวกรองแล้วหรือไม่	ตรวจสอบระยะเวลาทำความสะอาดและเปลี่ยนตัวกรอง จากนั้นทำความสะอาดหรือเปลี่ยนตัวกรอง
ไฟแสดงระดับมลพิษไม่มีการเปลี่ยนแปลง	• มีฝุ่นที่เลนส์ของเซนเซอร์มลพิษหรือไม่	ทำความสะอาดเลนส์ของเซนเซอร์มลพิษ (ดูที่หน้า 15)
	• ระดับมลพิษอยู่ในระดับสูงอย่างต่อเนื่องหรือไม่	ปรับความไวของเซนเซอร์มลพิษเป็นต่ำหรือมาตรฐาน (ดูที่หน้า 14)
	• ระดับมลพิษอยู่ในระดับต่ำอย่างต่อเนื่องหรือไม่	ปรับความไวของเซนเซอร์มลพิษเป็นสูงหรือมาตรฐาน (ดูที่หน้า 14)
มีกลิ่นเหม็นออกจากช่องปล่อยอากาศ	• ถึงเวลาทำความสะอาดหรือเปลี่ยนตัวกรองแล้วหรือไม่	ตรวจสอบระยะเวลาทำความสะอาดและเปลี่ยนตัวกรอง จากนั้นทำความสะอาดหรือเปลี่ยนตัวกรอง
สัญญาณบอกระดับมลพิษกะพริบ	• ติดต่อศูนย์บริการ	
ข้อบกพร่องในการทำงานอื่นๆ	• ตรวจสอบปัญหา ถอดปลั๊กไฟ และติดต่อศูนย์บริการ	

ข้อมูลจำเพาะ

ชื่อผลิตภัณฑ์	**เครื่องฟอกอากาศ**
ชื่อรุ่น	AP-1019C
แรงดันไฟฟ้าตามพิกัด	220 V- 240 V~ 50 Hz, 60 Hz
เฟส	เฟสเดียว
การใช้พลังงาน	35 W
ระดับการหุ้มฉนวนผลิตภัณฑ์	อุปกรณ์ Class 2 ⧈
วิธีการเก็บฝุ่น	วิธีการเก็บฝุ่นเชิงกล (ตัวกรอง HEPA)
ตำแหน่งติดตั้ง	ในอาคาร
พื้นที่ทำงาน	33 m^2
ขนาดผลิตภัณฑ์	340 mm (กว้าง) x 165 mm (ยาว) x 469 mm (สูง)
น้ำหนักผลิตภัณฑ์	5.5 kg

- ข้อมูลจำเพาะอาจมีการเปลี่ยนแปลงเล็กน้อยเนื่องจากการปรับปรุงประสิทธิภาพของผลิตภัณฑ์

MADE IN KOREA

001

9238271

coway

www.coway.com